



UK Custom Covers
Custom Designed For Ultimate Protection

Fitting Instructions BB196UKCC

Peugeot Partner/Citroen Berlingo Carbon Bonnet Bra 2008-2018

Fit as per the pictures below:



Please ensure both corners of the bonnet bra are fitted FIRST.



Fit as per the pictures to the left

Prior to fitting please ensure the bonnet bra is at room temperature (at least 24 degrees) for 12 hours. Failure to do so could cause damage to the bonnet bra. UK Custom Covers are unable to take responsibility for any damage caused to the bonnet bra if these fitting instructions are not followed.