



## Fitting Instructions QBL267UKCC

Volvo

XC60 2008 - 2017

### IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

1. Remove Parcel Shelf
2. Lay rear seats in the forward position and slot the two foam pads into the gap between the seats and the boot floor, Place the seats back in the upright position.
3. Attached to the liner are 3 elastic tapes, pass these around the relevant headrests.
4. To secure the sides of the liner into place, attach the Velcro supplied to the relevant points on the side of the liner, using the liner as a guide attach directly to the trim/carpet.
5. At the tailgate end of the liner attach the Velcro supplied to the relevant points.
6. To protect while loading/unloading attach the bumper flap to the relevant point on the tailgate end of the liner.

Important notice please read before use

Once the liner has been installed - Before lowering the rear seats you must remove the D Rings from the rear headrests – failure to do this could damage the liner.

UK Custom Covers will be unable to replace or refund any damaged liners where the above has occurred

### Velcro fixing kit

76 inches supplied (please cut to the required lengths)