



Fitting Instructions 031

Volvo

V70/XC70 2007 - 2016

IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

1. Lay rear seats in the forward position
2. Remove the two retractable dog guards and place the liner over the rear seat
3. Refit the dog guards (put rear seats in the upright position)
4. Place the headrest elastics – located on the upper edge of the boot liner - over the headrests
5. Fit the boot liner into place and secure the 4 floor fixings to the adjustable sliders in the floor tracks
6. To secure the sides of the liner into place, attach the Velcro tapes located on the sides of the liner to the relevant points fitted in the Volvo V70
7. To obtain the perfect fit – the sides of the liner can be secured by the 2 lengths of Velcro supplied, to obtain the correct location of the Velcro points use the liner as a guide

Velcro fixing kit

2 x 29 inch