



Fitting Instructions 048

Audi

Q7 2006-2015

IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

This is a 2 part liner

Part 1

1. Remove luggage blind
2. Secure the 3 velcro attachments at the rear of the liner, around the headrest locator pins
3. Use the 2 ties in the base of the liner to attach to the relevant anchor points
4. Carefully position the side panels neatly into place, attach 10 of the 2 inch velcro strips and 2 of the 14 inch and 6 of the 3 inch strips of velcro supplied to the corresponding velcro points on the liner. Using the liner as a guide attach directly to the sides of the vehicle.

Part 2

1. Attach the 19 x 2 inch Velcro strips to the relevant points on the tailgate protector, using the liner as a guide attach directly to the tailgate.

Velcro fixing kit

29 x 2 inch

6 x 3 inch

2 x 14 inch

(1 x 104 Inch velcro strip supplied, please cut to length as required)