



UK Custom Covers
Custom Designs For Ultimate Protection

Fitting Instructions 141

Ford

S-Max 2006-2014

1. Remove the load cover cassette
2. Take the liner out of its carry case and place in the vehicle so that the base fits neatly into position. The panel with the UK Custom Covers label attached sits against the back of the rear seat.
3. Attached to the front of the liner are Velcro straps, align these to the headrest locator poles.
4. Pass the tapes around each headrest locator pole and Velcro back onto themselves.
5. Carefully position the side panels neatly into place, using the liner as a guide attach the velcro tabs to the plastic trim of the vehicle.
6. If you wish to reinstate the load cover cassette you will need to cut some small access holes in each side of the liner, please pictures below:



Before cutting the access hole's



After cutting the access hole's

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD

Velcro Fitting Kit

24 X 2 Inch Tabs