



## Fitting Instructions

### VW Tiguan Boot Liner 2016 Onwards Generation 2 (BL285) – RAISED FLOOR VERSION

Thank you for purchasing your boot liner from our family-run business. Please follow the steps below to install your liner.

**Our liner requires your rear seats to be positioned towards the rear, and the false floor be in the highest position.**

This is a 2 part liner.

#### **PART 1 – THE MAIN LINER**

1. Before you start you'll need to cut the supplied Velcro as follows for the liner: 14 x 2" long pieces, and 2 x 27" long pieces.

#### ***ATTACH THE BASE FIRST ...***

2. Lay the liner in approximate position in the boot of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward. Flatten the base so it fits snugly against the boot edges.

#### ***NOW FOR THE BACK OF THE SEATS ...***

3. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

#### ***NOW THE SIDES & TAILGATE END ...***

4. Place the side panels in position, pushing the pockets of the boot liner into the recesses on each side.
5. Push the metal D-ring through the holes on each side.
6. Attach the pieces of Velcro that you cut earlier directly to the sewn in Velcro points on each side of the liner (7 x 2" and 1 x 27" to each side) as shown on sketch A. Using the liner as a guide affix the Velcro to the sides of your vehicle.

#### **PART 2 – REMOVEABLE BUMPER FLAP**

7. Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

**PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD**

### IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

### **SKETCH A**

**■ = INDICATES AREAS WHERE A 2" ADHESIVE-BACKED VELCRO PIECE NEEDS TO BE APPLIED**

