



BL447UKCC

Fitting Instructions BL447UKCC

Audi Q7 (Including SQ7) 2015 Onwards (7 Seater with 3rd Row Folded)

IMPORTANT PREPARATION NOTES

Before attaching the self adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

Main Liner

- Before Installing the Boot liner please lay the liner out on a clean surface with the shiny side up, on the liner you will see Velcro sewn into the liner. Using the Velcro provided, please cut into 6 x 2 inch lengths - to use on the three "D" shape tabs on each side of the liner, pictured:
- Apply the Velcro tabs that you have previously cut to the corresponding Velcro strips that are sewn on the boot liner (the three D shape tabs pictured) , leaving the backing of the self adhesive Velcro on the strips that have been cut.
- Place the boot liner in the boot area of the vehicle, please ensure the liner is placed shiny side down. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.
- Place the side panels in position, pushing the pockets of the boot liner into the recesses on each side if applicable. The Velcro sewn into the liner will attach directly to the carpet around the boot area.
- To attach the bumper flap, simply match up the Velcro on the liner itself with the liner sewn into the edge of the bumper flap piece.



PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD

Velcro Fixing Kit – 12 Inches, please cut Velcro supplied into 6 x 2 inch lengths.