



UK Custom Covers

Custom Designs For Ultimate Protection

Fitting Instructions BL649UKCC

BMW 3 Series Touring (G21) 2019 Onwards (**Not suitable for plugin Hybrid models**)

IMPORTANT PREPARATION NOTES

Before attaching the self adhesive Velcro (IF applicable) to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

Part 1 - Main Liner

- Before Installing the Boot liner please lay the liner out on a clean surface with the shiny side up, on the liner you will see small Velcro segments, using the Velcro provided please cut to the relevant sizes as seen on the boot liner.
- Apply the Velcro tabs that you have previously cut to the corresponding Velcro strips that are sewn on the boot liner, leaving the backing of the self-adhesive Velcro on the strips that have been cut.
- Place the boot liner in the boot area of the vehicle, please ensure the liner is placed shiny side down. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.
- Place the side panels in position, push the pockets of the boot liner into the recesses on each side if applicable. Once the Velcro strips are straight and in the correct position at the sides, peel the backing strips off and secure to the vehicle. At the tailgate end (around the boot opening) using the liner as a guide peel off the backing of the Velcro and attach directly to the vehicle.

Part 2 – Removeable Bumper Flap

- Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD

Velcro Fixing Kit – 72 Inches (Loop), please cut Velcro supplied to the relevant sizes.