



## Fitting Instructions QBL217UKCC

Audi

A6/Allroad Quilted Boot Liner 2011 - 2018

### IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

1. Remove the load cover cassette.
2. Unlock the rear seat backs and fold forward a little.
3. Take the liner out of its carry case and place in the vehicle so that the base fits neatly into position. The panel with the UK Custom Covers label attached sits against the back of the rear seat.
4. Starting at the seat end of the base, locate the two foam pads and push them down into the void between the floor and the seat backs. Lock the rear seats back into position trapping in the foam pads. Leave the seats in the unlocked position.
5. At the tailgate end where the liner meets the rear of the vehicle (NOT the bumper flap) attach 3 of the 5 inch velcro strips supplied to the 3 velcro strips sewn onto the base of the liner, then attach this directly to the carpet using the liner as your guide.
6. Attached to the front of the liner are velcro straps, align these to the headrest locator poles.
7. Pass the tapes around each headrest locator pole and velcro back onto themselves.
8. Open the access panel located on the left and right hand side of the vehicle and place the large elastic loop over the top, then close shut to secure.
9. Carefully position the side panels neatly into place.
10. On the left and right hand side of the liner attach 3 of the 2 inch strips of velcro supplied to the corresponding velcro strips sewn onto the sides of the liner. Using the liner as a guide attach directly to the side carpet.



**UK Custom Covers**  
Custom Designs For Ultimate Protection

11. Attach the 2 hooks to the rear seat locking points – Lock the rear seats back into position - Stretch the bungee and attach to the relevant hooks in the car.
12. Tuck the leading edge of the liner behind the tailgate seal.
13. To position the bumper flap in the upright position, attach the 4 inch velcro supplied to the velcro tabs sewn onto the bumper flap, remove the velcro backing and using the liner as a guide, attach to the gutters of the tailgate.

**PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD**

Velcro Fixing Kit – 3 x 5 inch plus 6 x 2 inch plus 2 x 4 inch

(1 x35 Inch velcro strip supplied, please cut to length as required)