



QBL318UKCC

## Fitting Instructions QBL318UKCC

Volkswagon

Passat Estate Quilted Boot Liner (Including Alltrack) 2015 Onwards

### IMPORTANT PREPARATION NOTES

Before attaching the self adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

### NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

1. Lay the liner in the boot area of the vehicle ensuring the panel with the UK Custom Covers tag is located by the rear seats.
2. Fasten the Velcro straps sewn onto the liner around the rear headrest locator poles.
3. Carefully place the sides of the liner into position, the Velcro attached to the sides of the liner will attach directly to the carpet including the parts of the liner that should be applied into the recess areas on each side of the boot area.

**Please note; No self adhesive Velcro is required to fit this boot liner**