



**UK Custom Covers**  
Custom Designs For Ultimate Protection

**SB765UKCC**

## **Ford Transit Custom / Tourneo Interior Screen Curtain Blind – SB765**

Fit as per the pictures below:



Tools Required: Phillips Screwdriver, Electric Drill, 2.5mm Drill Bit

Prior to fitting the windscreen curtain you will need to fit three poppers to each of the front 'A' pillar trims. The poppers need to be positioned at each end of the groove that runs down the middle of the trim (Pictured to the left). If you do not have this groove – hold the front blind up where it will go and use as a guide to place where the poppers need to go.



Driver's and Passenger's Door Curtains: Place the curtain up to the door and attach the magnets that are built into the curtain to the metalwork surrounding the window. You can make adjustments for the best fit and tuck the curtain in at the bottom.

