



TL244UKCC

NISSAN NAVARA NP300 CARPET LOAD BED LINER 2016 ONWARDS – BLACK – 244

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED.

NOTE: THE ADHESIVE TAKES 24HRS TO REACH FULL ADHESION

Fitting Tips

- Lay the truck liner in the bed of the truck
- Using the liner as a guide attach the provided self-adhesive (Double Strips) velcro to the relevant points of the truck bed (Plastic/Metal)
- Attach the velcro to the relevant points on the truck liner



Velcro fitting kit – 8 x 5 inch strips of **hook** velcro (40 inches total) – velcro is supplied in one strip, please cut to the sizes advised